

# SeaHawk LD310 Internal Diagram

JP1 - Leak Sensitivity  
 Top 2 Pins - Most sensitive  
 No Jumper - Medium sensitivity  
 Bottom 2 Pins - Least sensitive

JP2 - Relay Output Configuration  
 Top 2 Pins - Supervised  
 Bottom 2 Pins - Non-supervised

JP3 - Audible Alarm  
 Top 2 Pins - Disabled  
 Bottom 2 Pins - Enabled

L Brackets


Audible Alarm

LED

Silence/Test/Reset Button

Circuit Board Clip

Leader Cable / Leak Detection Input



Be sure the leader cable is wired into the correct pinouts.

Plastic Peg

5VDC Power Input

Cable Fault Relay Output

Leak Relay Output

Plastic Peg

